



HINDLE PRODUCTS LTD.

140 North Port Road
Port Perry, Ontario
L9L 1B2, CANADA

Tel. (905) 985-6111 | Fax. (905) 985-7349



GSX-R600/GSX-R750 ALIENHEAD FULL SYSTEM MOUNTING INSTRUCTIONS

TOOLS REQUIRED:

High temperature silicone (not included)	Spring installer tool (included)
Metric Socket set (not included)	Metric Allen Key set (not included)
Metric Wrench set (not included)	Small Flat Head Screwdriver
Electrical Tape	Liquid Electrical Tape
Heat Gun or Hair Dryer	Zip tie
Heat Shrink Tubing	Original Owner's Manual
45mm bolts x 2 (included)	Triangular Muffler Bracket (included)
20mm bolt (included)	

To install the AlienHead Hindle Exhaust System for GSX-R600 & GSX-R750 (2006-2009):

1. Read both sides of instructions before installing exhaust system.
2. Remove stock exhaust system as per owner's manual.
3. Using new gaskets (not included), install flanges onto motor.
4. Tighten flange nuts finger tight. Hang springs from holes on bottom of flanges.
5. Check that spring on flange lines up with spring tabs on primary tubes.
6. Use high temperature silicone sealant on the inside of primary tubes to install them onto the flanges.
7. Push primary all the way into flanges.
8. Tighten flange nuts evenly. Do not over tighten and bend flanges.
9. Install spring onto primary spring tabs using spring tool provided with system.
10. Install collector onto primaries using high temperature silicone sealant on the inside of collector and install springs.
11. Install elbow onto collector using high temperature silicone sealant on inside of elbow and install springs.
12. Slide muffler over top of elbow. Use small amount of high temperature sealant on the inside of the muffler.
13. Remove stock bolts from footpeg (near brake).
14. Install muffler bracket (triangular piece) behind footpeg (against the frame of the motorcycle) by using the two 45mm bolts (supplied). Re-install the stock footpeg using the Hindle bolts (supplied).
15. Use the 20mm bolt (supplied) to attach the Hindle megaphone muffler to the bracket (triangular piece).
16. Enjoy the added performance of your new Hindle Exhaust System!

GSX-R600/GSX-R750 SPECIAL WIRING INSTRUCTIONS

The SET (Suzuki Exhaust Tuning) can be disabled following these instructions:

1. Remove seat and metal brace by removing the four (4) bolts.
2. Make sure ignition is in OFF position.
3. Disconnect the black wire harness plug from the ECU.

Continued on following page

4. Remove the orange cap by pressing the tabs apart and pulling the cap off.
5. Pull out the black wire with brown stripe (the black wire with brown stripe can be found while holding the black plug with the locking tab facing down, on the top row and in the 5th position from the left).
6. Insert a small flat head screwdriver (or similar) into the hole. Lightly pry down with the screwdriver (or similar) to unlock the wire. Pull on the black wire with brown stripe to remove from the rear of the plug.
7. Completely seal off the disconnected wire to prevent electrical problems.
8. Use liquid electrical tape to seal tip of wire by immersing end of wire into liquid electrical tape.
9. After liquid is dry, slide a 1.5" piece of heat shrink tubing over the end of the disconnected wire and fold the remaining 0.5" of heat shrink tubing to create a tight seal.
10. Slide a slightly larger piece of shrink tubing over the folded section.
11. Using a heat gun or hair-dryer, heat the shrink tubing to create a tight seal. Careful! Wire may become hot.
12. Secure disconnected wire to harness using a zip-tie.
13. Reinstall orange cap onto black wiring harness plug and reconnect to ECU.
14. Reinstall metal brace and seat.
15. Completely remove the exhaust valve cables from the EXCVA servo (refer to owner's manual). DO NOT UNPLUG EXCVA servo.

12 MONTH LIMITED WARRANTY AND LIABILITY DISCLAIMER

Hindle Products Ltd. warrants this product free from defects in material or workmanship for a period of 12 months from the date of purchase, except as noted. The product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product, improper installation, exposure to harsh weather and/or chemicals, lack of proper maintenance, or any other conditions that are beyond the control of Hindle Products Ltd. Hindle Products Ltd. shall not be responsible for any type of incidental, consequential, or special damages. All implied warranties, including but not limited to those warranties of fitness and merchantability, are limited in the total duration to 12 months from the original purchase date. Hindle will not warrant any product for fitment issues after the system has been ran on the motorcycle for any length of time. If the warranty occurs within 30 days from the date of purchase, please contact the dealer product was purchased from. Over 30 days from the date of purchase, please contact Hindle Products Ltd. direct at (905) 985-6111 before shipping the product. Customer must contact Hindle Products Ltd. prior to sending warranty product. Claims for lost shipment, damaged shipments, or other problems regarding freight must be made directly to the responsible carrier. To obtain warranty service on Hindle Exhaust System products, mail the product prepaid and a copy of your dated sales receipt (as proof of purchase), together with a note explaining the reason for repair to this item to: **Hindle Products Ltd., 140 North Port Road, Port Perry, Ontario, Canada, L9L 1B2.** Product being returned without notification prior to shipping will be overlooked. Upon receipt, Hindle Products Ltd. will repair or replace, as appropriate, your Hindle product and return it to you, post paid. Warranty is solely through Hindle Products Ltd. Service to our products by anyone other than Hindle Products Ltd. voids warranty. Hindle Products Ltd. disclaims any and all liability for consequential or incidental damages. Hindle Products Ltd. will not be held responsible for personal damage, bodily harm or any other legal matters.

CAUTION: Exhaust system(s) and muffler(s) may be hot when engine is/has been running. Take preventative measures with the handling of any Hindle system or Hindle muffler. Allow the engine to cool before installing or removing the exhaust system and/or muffler. Severe burns, bodily injury and/or death may occur. Keep flammable materials away from exhaust at all times. Start and run the motorcycle in a well-ventilated area. Failure to do so may cause injury, bodily harm and/or death.