



140 North Port Road, Port Perry, Ontario, Canada, L9L 1B2  
Tel.: 905-985-6111 | Fax: 905-985-7349 | E-Mail: [info@hindle.com](mailto:info@hindle.com)  
[WWW.HINDLE.COM](http://WWW.HINDLE.COM)

**FEEL MORE POWER.**

**Installation Instructions for KTM 790 DUKE & 890 DUKE EVOLUTION  
MEGAPHONE/EVOLUTION MUFFLER (2018-2022) Slip-On**

---

To install the 2018-2022 KTM 790 DUKE & KTM 890 DUKE EVOLUTION MEGAPHONE/  
EVOLUTION MUFFLER SLIP-ON, proceed with the following directions:

**Caution: Do not install exhaust while engine is running, and/or is hot to the touch. Thoroughly read and review all steps of installation instructions to ensure proper installation. If you have any questions about installation, please contact us at 905-985-6111 and we would be happy to help.**



**Step 1:** Remove stock mid-pipe/elbow and muffler, as per owner's manual.

**Step 2:** Remove stock clamp and gasket on stock collector. *See Images 1, 2 & 3.*



Image 1



Image 2



Image 3

**Step 3:** Install Hindle mid-pipe/elbow onto the stock headers. Install Hindle muffler onto Hindle mid-pipe/elbow.

**Step 4:** If you are retaining the stock rear foot peg mount, mount the Hindle muffler or megaphone on the inside of the footpeg to the stock location. Remove protective film on muffler strap. Install protective rubber inside of the muffler strap making sure that the strap is inside the outer edge of the rubber. The top ends of the muffler strap should be pinched together, then installed using the stock nut. Install springs on mid-pipe to muffler. *See Images 3 & 4.*



Image 4



Image 5

**Step 5:** If you are eliminating the stock rear foot peg mount, use the “U” shape bracket provided. Install the 0.25” spacer onto the 40mm bolt and washer (provided). Install the 0.5” spacer on the 30mm bolt and washer (provided). **VERY IMPORTANT: install the 40mm bolt with spacer assembly on the left side of the bracket, and install the 30mm bolt with spacer assembly on the right side of the bracket.** See *Image 6* and *Image 7*.



Image 6

**Step 6:** If using the “U” shape bracket, remove protective film on muffler strap. Install protective rubber band inside of the muffler strap making sure that the strap is inside of the outer edge of the rubber. The top ends of the muffler strap should be pinched together. Install muffler strap to “U” shape bracket using supplied 8x20mm bolt, 2 washers and nut. Install springs onto mid-pipe and muffler using the spring tool provided. If installing the Evolution megaphone, attach to “U” shape bracket supplied 8x20mm bolt, 2 washer and nut. See *Image 8*.



Image 7

**Step 7:** Check overall clearance on exhaust installation before start up.

**Step 8: \*VERY IMPORTANT\*** A break-in procedure must be performed for new Hindle mufflers. Once installed, Hindle muffler must be warmed up by running the engine at idle for 15 minutes. Hindle muffler should then be left to cool down for 15 minutes. This process will help prolong the life of your Hindle muffler by helping set the internal muffler packing before first use. **Please note: Hindle mufflers require general maintenance: repacking of the muffler should be done, when required. Repacking will help protect the muffler’s outer shell, as well as noise and exhaust emissions.**



Image 8

*Enjoy the quality and performance of your new Hindle Exhaust System!*



# WARNING

**Exhaust system(s) and muffler(s) may be hot when engine is/has been running. Take preventative measures with the handling of any Hindle system or Hindle muffler. Allow the engine to cool before installing or removing the exhaust system and/or muffler. Severe burns, bodily injury and/or death may occur.**



# WARNING

**Keep flammable materials away from exhaust at all times.**



# WARNING

**Exhaust gas contains poisonous carbon monoxide that can rapidly accumulate in an enclosed or poorly ventilated area. If inhaled, it may cause serious injury or death. Start and run the motorcycle in a well-ventilated area.**

## **WARNING: USA CUSTOMERS:**

Certain states in the USA have individual laws regulating the use of aftermarket exhaust parts and systems, especially as those parts and systems modify, remove, or replace original equipment catalytic converters. Please become familiar with the appropriate laws in your area before installing any aftermarket part or system on your vehicle. to ensure compliance with all applicable laws. Hindle Products Ltd, Woodcraft Technologies Inc and any of their representatives, subsidiaries or the sellers of these parts or systems make any representation that any of their parts or systems comply with any of these laws for street use.

## **WARNING: CALIFORNIA CUSTOMERS:**

California laws prohibit the use of any aftermarket exhaust part or system that modifies, removes or replaces original equipment catalytic converters on any vehicle intended for street use. In California these parts or systems are only exempted from this law when they are used exclusively on racing vehicles on closed courses. Neither Hindle Products Ltd, Woodcraft Technologies Inc nor any of their representatives or subsidiaries make any representation that any of their parts or systems are approved for street use in California. The purchasers of Hindle products are entirely responsible for informing themselves of applicable California laws and to comply with those laws.

## **12 MONTH LIMITED WARRANTY AND LIABILITY DISCLAIMER:**

Hindle Products Ltd. warrants this product free from defects in material or workmanship for a period of 12 months from the date of purchase, except as noted. The product warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product, improper installation, exposure to harsh weather and/or chemicals, lack of proper maintenance, or any other conditions that are beyond the control of Hindle Products Ltd. Hindle Products Ltd. shall not be responsible for any type of incidental, consequential, or special damages. All implied warranties, including but not limited to those warranties of fitness and merchantability, are limited in the total duration to 12 months from the original purchase date. Hindle will not warrant any product for fitment issues after the system has been ran on the motorcycle for any length of time. If the warranty occurs within 30 days from the date of purchase, please contact the dealer product was purchased from. Over 30 days from the date of purchase, please contact Hindle Products Ltd. direct at (905) 985-6111 before shipping the product. Customer must contact Hindle Products Ltd. prior to sending warranty product. Claims for lost shipment, damaged shipments, or other problems regarding freight must be made directly to the responsible carrier. To obtain warranty service on Hindle Exhaust System products, mail the product prepaid and a copy of your dated sales receipt (as proof of purchase), together with a note explaining the reason for repair to this item to: **Hindle Products Ltd., 140 North Port Road, Port Perry, Ontario, Canada, L9L 1B2.** Product being returned without notification prior to shipping will be overlooked. Upon receipt, Hindle Products Ltd. will repair or replace, as appropriate, your Hindle product and return it to you, post paid. Warranty is solely through Hindle Products Ltd. Service to our products by anyone other than Hindle Products Ltd. voids warranty. Hindle Products Ltd. disclaims any and all liability for consequential or incidental damages. Hindle Products Ltd. will not be held responsible for personal damage, bodily harm or any other legal matters.